



3.3KW EVPT23 Series charger Fault LED Status

Fault code	Fault name	LED indicator
F1	Communication timeout failure	Red flashes twice and green flashes once, with a cycle interval of 3s
F2	AV voltage failure	Red flashes 3 times and green flashes once, with a cycle interval of 3s
F3	Battery voltage too low	Red flashes 4 times and green flashes once, with a cycle interval of 3s
F4	Battery voltage too high	Red flashes 5 times and green flashes once, with a cycle interval of 3s
F5	Over temperature fault	Red flashes 6 times and green flashes once, with a cycle interval of 3s
F6	The charging time has expired	Red flashes 7 times and green flashes once, with a cycle interval of 3s
F7	Charging capacity exceeded	Red flashes 8 times and green flashes once, with a cycle interval of 3s
F8	Hardware failure	Red flashes 9 times and green flashes once, with a cycle interval of 3s



Remark:

1. When the F3, F4, F6 and F7 fault codes are reported, please check whether the battery voltage and capacity are correctly matched, or the battery is seriously over-discharged.
2. When the F2 fault code is reported, please check whether the input voltage is within the normal range, or unplug the AC power plug and plug it in again after 1 minute.
3. F8 fault code is reported. Please check whether the input voltage is in the normal range and whether the battery voltage matches correctly, or pull out the AC power plug and plug it in again after 1 minute. If it still does not work properly, return it to the factory for repair.